



Instructions manual

Series FLOMAT
Sensor FLOMAT-FX
Converter MX4



The art of measuring

PREFACE

Thank you for choosing a product from Tecfluid S.A.

This instruction manual allows the installation, configuration, programming and maintenance. It is recommended to read it before using the equipment.

WARNINGS

- This document shall not be copied or disclosed in whole or in any part by any means, without the written permission of Tecfluid S.A.
- Tecfluid S.A. reserve the right to make changes as deemed necessary at any time and without notice, in order to improve the quality and safety, with no obligation to update this manual.
- Make sure this manual goes to the end user.
- Keep this manual in a place where you can find it when you need it.
- In case of loss, ask for a new manual or download it directly from our website www.tecfluid.com Downloads section.
- Any deviation from the procedures described in this instruction manual, may cause user safety risks, damage of the unit or cause errors in the equipment performance.
- Do not modify the equipment without permission. Tecfluid S.A. are not responsible for any problems caused by a change not allowed. If you need to modify the equipment for any reason, please contact us in advance.

TABLE OF CONTENTS

SENSOR FLOMAT-FX

| | | |
|---|--|----|
| 1 | WORKING PRINCIPLE | 6 |
| 2 | RECEPTION | 6 |
| | 2.1 Unpacking | 6 |
| | 2.2 Storage temperature | 6 |
| 3 | HANDLING | 7 |
| 4 | INSTALLATION | 7 |
| | 4.1 Sensor position | 7 |
| | 4.2 Straight pipe sections | 8 |
| | 4.3 Valves | 8 |
| | 4.4 Pumps | 8 |
| | 4.5 Aeration | 10 |
| | 4.6 Vibrations | 10 |
| | 4.7 Magnetic fields | 11 |
| | 4.8 Temperature | 11 |
| 5 | MOUNTING | 12 |
| | 5.1 Pipe adaptor mounting | 12 |
| | 5.2 Sensor mounting | 14 |
| | 5.3 Tightening torque | 14 |
| | 5.4 Electronic converter connection | 14 |
| | 5.5 Electronic converter programming | 14 |

MX4 CONVERTER

| | | |
|---|---------------------------------------|----|
| 1 | INTRODUCTION | 15 |
| 2 | INSTALLATION | 15 |
| | 2.1 Sensor connection | 15 |
| | 2.1.1 Compact converter | 15 |
| | 2.1.2 Remote converter | 16 |
| | 2.2 Electrical connection | 16 |
| | 2.2.1 Power supply wiring | 17 |
| | 2.2.2 Relay output wiring | 17 |
| | 2.2.3 Remote reset input wiring | 18 |

| | | | |
|---|-------|-------------------------------------|----|
| | 2.2.4 | Analog output wiring | 19 |
| | 2.2.5 | Pulse output wiring | 20 |
| 3 | | REMOTE SENSOR | 21 |
| | 3.1 | Preparing the cable | 21 |
| | 3.2 | Cable installation | 23 |
| | 3.3 | Cable connection to sensor | 23 |
| | 3.4 | Cable connection to converter | 24 |
| | 3.5 | Cable specifications | 25 |
| 4 | | CONVERTER INTERFACE | 26 |
| 5 | | MAIN MENU | 27 |
| | 5.1 | Passwords to access the menus | 27 |
| 6 | | INSTALLATION PARAMETERS | 29 |
| | 6.1 | Language | 30 |
| | 6.2 | Sensor factor | 30 |
| | 6.3 | Converter factor | 30 |
| | 6.4 | Nominal diameter | 30 |
| | 6.5 | Diagnosis | 30 |
| | 6.5.1 | Parameters | 31 |
| | 6.5.2 | Simulator | 31 |
| | 6.5.3 | Mains frequency | 32 |
| | 6.5.4 | Coil current | 32 |
| 7 | | CONVERTER PROGRAMMING | 33 |
| | 7.1 | Language | 33 |
| | 7.2 | Units | 34 |
| | 7.3 | Flow rate decimals | 34 |
| | 7.4 | Flow rate | 35 |
| | 7.4.1 | Empty pipe | 35 |
| | 7.4.2 | Cut off | 35 |
| | 7.4.3 | Reversal flow rate | 36 |
| | 7.4.4 | Damping | 36 |
| | 7.4.5 | Offset | 37 |
| | 7.5 | Outputs | 37 |
| | 7.5.1 | Relay 1 and relay 2 | 37 |

| | | |
|---------|---|----|
| 7.5.1.1 | Alarm | 38 |
| 7.5.1.2 | Empty pipe | 38 |
| 7.5.1.3 | Negative flow | 38 |
| 7.5.2 | Pulse output | 38 |
| 7.5.2.1 | Pulse output configuration | 38 |
| 7.5.2.2 | Units | 39 |
| 7.5.2.3 | Pulses | 39 |
| 7.5.2.4 | Duty cycle | 39 |
| 7.5.3 | Analog output | 39 |
| 7.5.3.1 | 4-20 mA output configuration | 40 |
| 7.5.3.2 | Programming of the 4-20 mA output | 40 |
| 7.5.3.3 | Current calibration for 4 and 20 mA | 40 |
| 7.6 | Working screen | 40 |
| 7.7 | Totalizer | 41 |
| 7.8 | Modbus | 42 |
| 8 | SERIAL NUMBER | 42 |
| 9 | SOFTWARE VERSION | 42 |
| 10 | WORKING SCREEN | 42 |
| 11 | STARTING CURRENT | 43 |
| 12 | ASSOCIATED SOFTWARE WINSMETER MX4 | 44 |
| 12.1 | USB cable connection and drivers installation | 44 |
| 12.2 | Port connection | 45 |
| 12.3 | Access to installation and programming | 46 |
| 12.4 | Datalogger | 49 |
| 12.5 | Visualization | 51 |
| 12.6 | Firmware update | 52 |
| 13 | TECHNICAL CHARACTERISTICS | 53 |
| 14 | MAINTENANCE | 54 |
| 14.1 | Fuse | 54 |
| 15 | SAFETY INSTRUCTIONS | 55 |
| 15.1 | Pressure equipment directive | 55 |
| 15.2 | Certificate of conformity TR CU (EAC marking) | 55 |
| 16 | DIMENSIONS | 56 |
| 17 | TROUBLESHOOTING | 60 |
| ANNEX A | Flow rate diagram | 62 |


SENSOR FLOMAT-FX

1 WORKING PRINCIPLE

The FLOMAT electromagnetic flowmeters are based on Faraday's induction law.

When an electrically conductive liquid flows through a magnetic field, perpendicular to the flow direction, it induces a voltage V proportional to the liquid velocity.

Two electrodes in contact with the liquid and positioned perpendicularly to the magnetic field, sense this voltage V .



$$V = B \cdot v \cdot d$$

Where:

V = Measured voltage in the electrodes

B = Magnetic field

v = Liquid velocity

d = Distance between electrodes

2 RECEPTION

The FLOMAT electromagnetic flowmeters are supplied conveniently packaged for transportation together with their instruction manual for installation and operation.

All the flowmeters have been verified in our calibration rigs to obtain the gain factor F_c for each sensor.

2.1 Unpacking

Unpack the instrument carefully, removing any remains of the packing.

2.2 Storage temperature

-20°C +60°C

3 HANDLING

It should always be done with care and without knocks.


4 INSTALLATION

This should be made in a straight pipe run that guarantees that the pipe is always completely full and where there is a fully developed turbulent flow profile (follow indications on point 4.2).

Avoid high points of the pipes where air pockets usually form, or pipes with downwards flow where vacuums can occur.


Partially full pipes can involve important reading errors.

Flow rate measurement with open discharge makes it necessary to install the flowmeter in a pipe section with a siphon which avoids stagnation of air in the sensor.



4.1 Sensor position

The optimum position to install the sensor is with the electrodes in the side of the pipe. This way, air pockets at the top of the pipe are avoided.




4.2 Straight pipe sections

The point where the FLOMAT sensor will be installed must be a straight pipe section, separated from elements that can disturb the flow profile, such as elbows, diameter changes, etc. Depending on the element the minimum necessary distances upstream from the sensor are shown on the next page (**BS 1042-2.2:1983 standard**).

Downstream, the minimum recommended distance to a disturbing element is 5 x DN.


4.3 Valves

Control valves or shut-off valves should always be installed downstream from the sensor to assure that the pipe is always full of liquid.




4.4 Pumps

Pumps should be mounted upstream from the sensor to avoid the suction of the pump (vacuum).




Disturbing element
upstream the
sensor

Minimum distance between
the sensor and the element




4.5 Aeration

If there is a point where the difference in level is higher than 5 m an air inlet valve should be installed after the sensor to avoid a vacuum effect that could damage the sensor.




4.6 Vibrations

Vibrations of the pipes should be avoided by anchoring the pipe before and after the sensor. The vibration level should be less than 2.2 g in the range of 20 -150 Hz according to IEC 068 -2-34.



4.7 Magnetic fields

Strong magnetic fields close to the sensor should be avoided.




4.8 Temperature

In open air installations it is recommended to install a protection to avoid direct sun light on the flowmeter.

With thermally insulated pipes DO NOT insulate the sensor. High temperatures can damage it.

The maximum liquid temperatures are shown on page 53.



5 MOUNTING


5.1 Pipe adaptor mounting

The sensor is normally supplied mounted in its pipe adaptor. Before welding the adaptor to the pipe, the sensor must be removed to avoid irreparable damage due to excessive temperatures.

There are two basic types of pipe adaptors: with threaded or with flanged connection.

For the smallest pipe diameters (DN40, 50 & 65) the pipe adaptor is supplied welded to a short length of pipe with a "T" form. For this type just couple it to the pipe by welding or gluing in the case of PVC, PP, PE or other plastics.

For DN80 and bigger, there are three lengths for each of the two types of fittings.




The process of putting the pipe adaptor in should be done accurately. The distance (H) (see drawings on next page) which is what the pipe adaptor should protrude above the surface of the pipe is important.

As shown in the following table, to know the distance, the thickness of the pipe **s** must be known.

In order to make the positioning of the pipe adaptor in the pipe easier, there is a label on one of its sides with markings indicating the position of the internal pipe diameter for each DN. Cut this label above the line corresponding to the DN of the pipe, at a distance equal to the pipe thickness. Peel off the bottom part of the label. Once the pipe adaptor is placed into the pipe in its final position, where the label was cut must coincide with the outer diameter of the pipe.

This ensures that the measuring electrodes penetrate far enough in the area of flow profile that will allow an accurate measurement.

| DN | C (mm) | Insert pipe adaptor | |
|------|--------|---------------------|--------|
| | | L (mm) | H (mm) |
| 80 | 10 | 93 | 88-s |
| 100 | 12.5 | | 85.5-s |
| 125 | 15.5 | | 82.5-s |
| 150 | 19 | | 79-s |
| 200 | 25 | | 73-s |
| 250 | 31 | | 67-s |
| 300 | 37.5 | | 60.5-s |
| 350 | 44 | | 54-s |
| 400 | 50 | | 48-s |
| 450 | 56 | | 42-s |
| 500 | 62,5 | | 145 |
| 600 | 75 | 128-s | |
| 700 | 87.5 | 115.5-s | |
| 800 | 100 | 103-s | |
| 900 | 112.5 | 90.5-s | |
| 1000 | 125 | 78-s | |
| 1200 | 150 | 205 | 203-s |
| 1400 | 175 | | 178-s |
| 1600 | 200 | | 153-s |
| 1800 | 225 | | 128-s |
| 2000 | 250 | | 103-s |



Example:

Suppose a pipe of 300 mm inner diameter (DN300) and 5.5 mm thick. In the chart we can see that the distance that the pipe adaptor must extend above the external wall is $H = 60.5 - s = 60.5 - 5.5 = 55$ mm.

The values in the chart are calculated considering the gasket supplied with the instrument, which is 3 mm thick. If the thickness of the gasket is changed, the value of H will change.

The equation to calculate H' for a gasket of thickness d is the following:

$$H' = H + 3 - d$$

In the previous example, if the gasket was 5 mm thick, the distance that the adaptor should extend above the external wall would be $H' = 55 + 3 - 5 = 53$ mm.

Drill a 48.5 mm diameter hole in the pipe to insert the pipe adaptor and weld the fitting to the pipe.

If the pipe is made of concrete or other material to which the pipe adaptor cannot be welded, a clamp-on accessory or saddle should be used. In this case, please contact us to inform about the suitable sensor length.



The axis of the pipe adaptor should be perfectly perpendicular to the pipe axis.

5.2 Sensor mounting

Once the pipe adaptor is mounted, place the flat seal in its position and install the sensor with the arrow pointing in the flow direction. The electrodes must be perfectly perpendicular to the pipe axis.

In order to align the sensor, the two bolts or pins situated in each side of the cylinder in the top of the FLOMAT sensor must be aligned with the axis of the pipe and the arrow pointing in the flow direction.

5.3 Tightening torque

The tightening torque for the flange screws should not exceed 7.1 Nm.

The tightening torque for the threaded fitting should not exceed 21 Nm.

5.4 Electronic converter connection

See point 2.1 on page 15.

5.5 Electronic converter programming

FLOMAT sensor is insertion type, so it can be installed in pipes with different diameters.



NOTE: It is essential to program the internal diameter of the pipe, in order that the converter can indicate the correct flow rate (see point 6.4 on page 30 or point 13.3 on page 46).

MX4 CONVERTER

1 INTRODUCTION

The MX4 converter unit can be used with the different FLOMID and FLOMAT series of electromagnetic flow sensors. The electronic circuit is based on the most advanced technology in digital signal processing, in order to obtain accurate and reliable measurements.

The device provides the following features:


- Coil excitation by means of pulsed signal to obtain a negligible zero offset.
- Pulse and current output proportional to the flow rate and user programmable.
- Relay outputs user programmable as flow rate alarm or status.
- Local and remote mounting.
- Easy exchange with other sensors.
- Graphic display with intuitive menus.
- Adjustable front cover in order to make display reading easier, depending on installation.

2 INSTALLATION

2.1 Sensor connection

2.1.1 Compact converter

The converter provides two cables to be connected to the sensor. Once connected, slide the converter along the sensor neck until the stop. Tight the two fixing screws.



2.1.2 Remote converter

One of the ends of the cable has a header and two wires, to connect them to the sensor. The connection is as explained in point 2.1.1.

The other end has to be connected to the converter, and has five wires. The cable must be passed through the cable gland and the connection for each wire is explained in chapter 3.

2.2 Electrical connection

For the electrical installation, the MX4 converter has two terminal strips. To help in the wiring of the equipment, the description of the terminals is marked on a label in the rear cover of the device.

For the electrical installation it is recommended to use multiple conductor cables with individual cable sections in the order of 0.25 to 0.5 mm² in order to make it easier to connect. It is better to maintain the cables with mains voltage (power supply) separated from the cables with low level signals (4-20 mA, etc.).

Before starting the installation, check that the cable glands are the right size for the cables to be used. This will guarantee the instrument will stay watertight. The cable glands used are for cables with outside diameters between 3.5 mm and 10 mm

To connect the cables, peel the outside insulation to free the inner cables. It is recommended to put a terminal at the ends of the wires to avoid loose ends. Pass the cables through the cable glands and screw down in the corresponding positions of the terminal strip. Once the wiring is finished make sure that the cables are well gripped by the cable glands to maintain the degree of protection.



Incorrect installation of the cable gland or inadequate cable placement can cause irreparable damage to the converter.



IMPORTANT NOTE: In order to comply with the electrical safety requirements as per EN-61010-1 (IEC 1010-1), the installation of the equipment must take into account the following:

- A mains switch must be provided to disconnect the equipment. This switch must be marked as the disconnecting device for the equipment and be within easy reach of the operator.
- The mains supply must have an earth line.
- The housing must not be opened when the instrument has mains supply connected.




IMPORTANT NOTE: To ensure smooth operation of the equipment, it is recommended to make the connection paying attention to the following points:

- For the output signals, use shielded cable when possible.
- Keep the cables away from strong sources of noise.

2.2.1 Power supply wiring


Before starting the installation of the equipment, check that the supply voltage available is the same as marked on the label of the converter.



| <u>Terminal</u> | <u>Power supply AC</u> | <u>Power supply DC</u> |
|-----------------|------------------------|------------------------|
| 8 | Earth | NC |
| 9 | Neutral | - |
| 10 | Phase | + |

It is very important to connect the mains earth to the instruments with AC power supply due to the presence of a mains filter inside the converter that uses this connection.

2.2.2 Relay output wiring




| <u>Terminal</u> | <u>Description</u> | <u>Relay</u> |
|-----------------|--------------------|--------------|
| 6 | Normally Open | Relay 1 |
| 5 | Common | Relay 1 |
| 4 | Normally Open | Relay 2 |
| 3 | Common | Relay 2 |


The relay outputs provide relays with potential free contacts (see characteristics in page 53).

The status of the relay contacts corresponds to the relay at rest.

The relay contacts are not protected in any way, and therefore they must be installed externally as required in the application, taking into account the limitations of the characteristics of such contacts. In the case of having inductive loads, and to extend the working life of the relay contacts, it is recommended to use overvoltage protection (VDR for AC and diodes for DC loads). In all cases a fuse or some kind of protection against short circuits, should always be provided according to the needs of the intended load.



2.2.3 Remote reset input wiring




Terminal

| | |
|---|---------|
| 1 | Contact |
| 2 | Contact |

These terminals correspond to an input that resets the value of the totalizer. A potential free normally open push button can be connected. The push button contact must be a good quality snap action switch to guarantee correct working at low voltages and reduce contact bounce effects.

2.2.4 Analog output wiring



Terminal



| | |
|----|-------------------------------|
| 11 | mA (positive, active output) |
| 12 | mA |
| 13 | mA (negative, passive output) |

The analog output is galvanically isolated. It can be either active (which means that the receiving device must be passive) or passive (which means that the receiver must supply the power for the current loop). It is recommended to use a receptor with an input resistance of less than 700 Ω to guarantee correct operation.


The configuration of the analog output mode (active or passive) is done by means of the connection to the terminal strip. For active mode, terminals 11 and 12 are connected. For passive mode, terminals 12 and 13 are connected.



NOTE: The analog output has protection against reversed polarity. Due to another protection against over voltages, if a loop supply voltage of more than 32 V is connected with reverse polarity, the converter may be damaged.



2.2.5 Pulse output wiring




Terminal

| | |
|----|-----------|
| 14 | Collector |
| 15 | Emitter |

The pulse output is opto-isolated. The terminals are the collector and emitter of a NPN bipolar transistor.


In the case of using inductive loads, in order to protect the output transistor, the use of free wheeling diodes is required.



Example. Connection with the load at the collector



Example. Connection with the load at the emitter



3 REMOTE SENSOR

When an installation requires that the electromagnetic sensor is separated from the control unit, the union between these two elements must be made by means of an interconnection cable.

These cables are supplied by Tecfluid S.A., already prepared for their direct connection to the sensor and the converter.



Important: The interconnection cable between the sensor and the converter must always be a single piece, without any kind of joint.

In the event of having to repair a broken cable at one of its ends, it should be cut at the breakage point and reworked for the connection at that point.

3.1 Preparing the cable


The ends of the cable should be prepared as shown in the drawing on next page. Special care should be taken to avoid possible short circuits between the shields. The point at which the shields are cut refers to the aluminium shields.


Electronics side

At the electronic unit's end, the ends of the cables should be striped at about 5 mm and then tined. Pair 1 (Red & Black) is for the excitation coils and Pair 2 (White & Black) is for the electrodes.

Sensor side

Pass the sensor side end through the cable gland of the sensor connector and then connect the cables of this end to the IDC connectors as shown in the following drawing. (the union between terminals 2 and 4 in Pair 2 must be taken into account).





3.2 Cable installation


The following points must be taken into account:

- The cable should be installed in a conduit or should be securely fixed, given that movements of the cable can induce reading errors.
- The cable should be placed as far as possible from sources of electrical noise such as switching gear and electrical machines.
- The maximum length of the connection cable depends on the fluid conductivity. For liquids with a conductivity higher than $500 \mu\text{S}/\text{cm}$ cable length can be up to 150 m.

3.3 Cable connection to sensor


For the sensor connection, first loosen the cable gland to allow the cable to slide in it.

- Make sure that the two fixing screws of the cover do not protrude inside the cover (this avoids damaging the O-ring of the sensor neck).
- Apply a few vaseline on the sensor neck to aid inserting in the cover, specially on the O-rings.
- Connect the two cable connectors in their corresponding male connectors on the sensor, mating the bumps in the guide of the male connectors.



- Slide the cover on the sensor neck until it meets its stop.
- Tighten the two fixing screws to anchor the cover.
- Tighten the cable gland to guarantee water tightness.

3.4 Cable connection to converter



Terminal

| | |
|-----------|-------------------------------|
| 16 | Top coil (red cable) |
| 17 | Bottom coil (black cable) |
| 18 | Rear electrode (white cable) |
| 19 | Ground (shield) |
| 20 | Front electrode (black cable) |

So that the flow direction shown in the instrument matches the actual direction, please take into account the cables colour scheme according to the figure on page 21.

3.5 Cable specifications

Model: CERVITRONIC PAR-POS Code 04754502

Construction

Conductor: Annealed electrolytic copper, tinned
As Norm: UNE 21064
Isolator: Polyolefin (PE - Solid)
Composition: By pars
Par shield: Tape Al/Pet + Drain Cu Sn
Cover : 100 % Physical
All over shield: Tape Al/Pet + Drain Cu Sn
Cover: 100 % Physical
Exterior cover: PVC
Colour: Black

Electrical characteristics


Working Voltage: 250 V
Testing Voltage: 1000 V
Electrical resistance: $\leq 52,2 \Omega/\text{km}$
Capacity: C* / C** 90-170 pF/m
C* capacity between conductors
C** capacity between one conductor and the rest connected to the shields

Physical characteristics

External diameter: 6.6 mm
Bending radius: 66 mm
Working temperature: -5°C ... +70°C
Fire risk: Does not propagate flame as per Norm IEC 60332-1 and EN 50265
Section: 0.34 mm²
Weight: 51 kg/km

Cable section


- 1 PVC cover
- 2 External shield wire
- 3 Insulating film
- 4 Pair 1/2 shield wire
- 5 PVC insulation
- 6 Pair 1/2 conductor




4 CONVERTER INTERFACE

The MX4 converter has a graphic LCD and a keyboard with 4 push buttons.

The keyboard has four numeric keys to introduce the values of installation and programming. Two of these keys are used also as cursors.



The following figure shows the functionality of the converter keys.




(Down / Left) To switch between flow rate, totalizer and fluid velocity screens.
To change to the digit on the left.
Into the menu, to scroll down.



(Up) To switch between flow rate, totalizer and fluid velocity screens. To increase the digit.
Into the menu, to scroll up.




(Enter) To validate the data.
To enter into installation and programming modes of the converter.
To exit from an informative text.



(Escape) To return to the previous menu.
To exit from a screen without validating data.

5 MAIN MENU

To access the main menu of the converter, press the key (Enter). The following screen appears:



The "Installation" option allows the basic configuration of the instrument, as explained in Chapter 6 of this manual.

The "Programming" option allows to program all parameters of the converter, as explained in Chapter 7 of this manual.

From the "Reset totalizer" option, the user can return the totalizer to zero. When exiting the menu, the totalizer will begin to accumulate again.

Note: The "Reset totalizer" operation requires the program password input (see point 5.1).

The options "Software Version" and "Serial Number" are informative and are discussed in Chapters 8 and 9 of this manual.

5.1 Passwords to access the menus



The password for the installation menu may be different from the password for the program menu.

By default, the equipment is factory configured with the password disabled.


If you want to change any of these passwords, you must enter the corresponding menu and once inside, access the submenu "Password".

To change the access password of the installation menu, select "Installation" on the main menu and then "Password".

To change the access password of the programming menu, select "Programming" in the main menu and then "Password".



When the "Password" option is selected, a screen that indicates the password status for this menu appears.




Selecting "Enable", the screen to enter the new password appears.




Once entered, the new password is asked again to avoid possible inadvertent error.




If the re-entered password does not match the first one, the following error message appears and the process should be carried out again.




If both passwords match, the following information message is displayed:



If the password needs to be changed or disabled, the procedure is the same. Once entered the "Password" menu, the following screen appears:



If Change is selected, the equipment will ask for a password again. If Disable is selected, the following message will appear:



6 INSTALLATION PARAMETERS

Power on the electronic converter with the voltage indicated on the label.


Press the (Enter) key in order to enter the main menu.

With the keys (Down / Left) and (Up), select "Installation", and then validate with the key (Enter).

In order to access to the Installation menu, a password must be entered. When accessing the first time, the default password is 0123. For more details about the password, see paragraph 5.1 on page 27.




Once the password is entered, and after pressing the key (Enter), the first screen allows to choose between the different options of the installation menu.




6.1 Language

You can choose the language in which all the menus will be displayed.




6.2 Sensor factor

In this screen the sensor factor is shown. It should coincide with the **F_c** parameter on the sensor label.




6.3 Converter factor

The electronic converter factor is shown. It should coincide with the **F_e** parameter on the converter label.



6.4 Nominal diameter


The value of the nominal diameter is always the internal diameter of the sensor.



6.5 Diagnosis

When the flowmeter is not working properly, it can be useful to test some parts of the instrument in order to locate the problem.

In this section a list with two possible options appears.



6.5.1 Parameters

This screen allows the diagnosis of the coil current, the differential voltage on the sensor electrodes, and the conductivity of the liquid.

| | |
|-------------------|-------------------------------------|
| PARAMETERS | |
| Coil : | <input type="checkbox"/> |
| Cond.: | <input checked="" type="checkbox"/> |
| Vdif : | 35 mV |

In the first row, a possible damage of the sensor coils can be detected. If there is a symbol V on this row, it means that the coils do not have any damage. If the symbol is X it means that the coils are damaged. In this case, please contact us.

The second row shows if the conductivity of the liquid is high enough for the instrument to perform the measurement process.

The conductivity of the liquid should always be higher than 20 $\mu\text{S} / \text{cm}$.

The third row shows the differential voltage value on the electrodes (Vdif).

This voltage appears in some cases where chemical reactions are created on the surface of the electrodes.

While this value does not exceed 500 mV the flowmeter can work properly. If the value is higher, there is no guarantee that the flow reading is correct. In this case, please contact us.

6.5.2 Simulator

With this diagnosis an electronic fault in the measuring circuit can be checked.

Before checking, disconnect the electrodes from the converter. To do this, if the converter is compact mounted, remove the electrodes IDC connector shown in the figure on page 15 (5-pin cable). If the converter is remote mounted, remove the electrodes wires (terminals 18, 19 and 20) of the terminal strip on the back (see page 24)

| |
|---|
| INFORMATION |
| Disconnect the cable from the electrodes |
| Press Enter |

Pressing Enter a screen indicating a simulated speed of the liquid is shown. If the circuit is working properly the displayed value will be between 4 and 6 m/s.

| | |
|------------------|--------|
| SIMULATOR | |
| Liquid velocity | |
| Min: 4 | Max: 6 |
| 5.23 | m/s |

To come back to the main menu, connect the electrodes cable again and press Escape key.

INFORMATION
Connect the cable
from the electrodes

Press Enter

Press again the Escape key until the working screen.

6.5.3 Mains frequency

If the power supply of the converter is AC, the following screen will appear:

FREQUENCY 1/2
▶ Manual
Automatic

Normally "Automatic" should be selected. In this case, the computer automatically detects the frequency of the mains and thus uses the most appropriate coil excitation to eliminate noise from the mains.

The detected frequency can be shown in the screen that appears when you select the automatic mode.

AUTOMATIC
Mains frequency

50.23 Hz

If manual mode is selected, the mains frequency can be chosen between the two most prevalent in all countries, 50 and 60 Hz

FREQUENCY 1/2
▶ 50 Hz
60 Hz

If the power supply of the converter is DC, this screen appears directly.

6.5.4 Coil current

In normal situations it is not necessary to change the coil current selected in the equipment by default.




NOTE: So that this change is effective, several jumpers inside the instrument need to be changed. In case that a different coil current must be used, please contact us.

7 CONVERTER PROGRAMMING


By programming the converter the visualization and the outputs of the instrument can be configured.

Turn on the converter and press (Enter) to enter the main menu. The following screen appears:




With the keys (Down / Left) and (Up), select Programming, and then validate with the key (Enter).

If the converter has the password option enabled, a password must be entered. For more details about the password, see section 5.1 on page 27.




Once the password is entered, the first screen allows to choose between the different programming options.



7.1 Language

The language in which all the menus will be displayed can be chosen.



7.2 Units

In this screen the units for the liquid velocity, the flow rate and the totalizer can be chosen independently.

| UNITS E/2 | |
|--|--|
| Velocity | |
| ▶ Flow rate | |
| Totalizer | |

| FLOW RATE E/12 | |
|---|--|
| US gal/h | |
| ▶ US gal/min | |
| US gal/s | |
| UK gal/h | |
| UK gal/min | |
| UK gal/s | |
| l/h | |
| l/min | |
| l/s | |
| m ³ /h | |
| m ³ /min | |
| m ³ /s | |

| VELOCITY E/2 | |
|---|--|
| m/s | |
| ▶ ft/s | |

| TOTAL E/4 | |
|--|--|
| US gal | |
| ▶ UK gal | |
| l | |
| m ³ | |

7.3 Flow rate decimals

In this screen the number of decimals for the flow rate indication can be selected.

| DECIMALS E/2 | |
|---|--|
| 0 | |
| ▶ 1 | |
| 2 | |

To select the number of decimals it must be taken into account that the instrument has 5 digits for flow rate indication. If two decimals have been selected, these will be seen whilst the flow rate is not higher than 999.99. Above this value the indication will automatically change to one decimal, and when the flow rate is higher than 9999.9 the indication will be done without decimals.


If one decimal is selected, the flow rate indication will have a maximum of one decimal until 9999.9. Above this value the indication will be done without decimals.

If indication without decimals is selected, the flow rate will always be shown without decimals.

For the selection of the flow rate units and the number of decimals it must be taken into account that an indication with an excess of decimals may give the sensation of instability of the reading. As a general rule it can be considered that the reading should not have more than a total of 5 digits (integer + decimals).


7.4 Flow rate

This screen displays a submenu to modify different aspects related to flow reading, such as empty pipe detection, cut off, reversal flow, filtering and offset.




7.4.1 Empty pipe


Detection can be programmed in two different ways.



In the event that Error is selected, when the converter detects empty pipe, it will display the following error message instead of readings.



If Warning is selected, in the event of detection of empty pipe, the converter will keep working normally and the symbol "!" will appear next to the measured value, indicating that the reading is not reliable.




7.4.2 Cut off

A cut off flow rate can be programmed, that means, the flow rate below which the flow rate indication will be zero. This can avoid reading errors in the lower zone of the scale. The maximum allowed value for the cut off is the equivalent to a liquid velocity of 1 m/s.



7.4.3 Reversal flow rate


The MX4 is a bi-directional converter. The flow rate changes its sign automatically when the flow is reversed. If after the converter has been installed it is necessary to reverse the flow rate sign, in this screen it can be done by selecting the option "REVERSAL- Yes".



7.4.4 Damping

The MX4 converter has an adaptive filter (damping) to provide stable flow rate and analog output readings in the presence of continuous flow rate fluctuations.

The configuration of this filter can be very useful in the cases where the flow rate readings have some instability (due to air bubbles, suspended solids, etc).



Only the flow rate indication of the display and the analog output are affected by the filter. The relay output and the totalizer act according to the instant flow rate. Selecting a filter with a longer or shorter integration time will provide more or less stable readings and will also affect the response time to small variations of flow rate.

The integration time is selected in seconds, with a minimum value of 0 and a maximum value of 40 seconds. For example, with an integration time of 15 seconds, the display will indicate the flow rate reading of the average flow rate over the last 15 seconds from the last update of the display. This does not mean that the display is refreshing its data every 15 seconds. The display shows a new value several times per second, indicating an average of the flow rate values of the last 15 seconds.

When there is a sudden variation of the flow rate then the filter should react as fast as possible to give a correct reading of the new value. For this, the filter controls the deviation of the instant flow rate with respect to a reference for each reading. If this deviation exceeds the 10%, the filter will stop acting, indicating the instant value, and will start again the filtering process.

7.4.5 Offset



In order to obtain a perfect linearization of the instrument, it is recommended to make an adjustment of the zero offset each time an installation is performed.

The flow rate must be zero, that is, the liquid inside the pipe where the flowmeter is installed should be completely stopped. Furthermore, a completely full pipe is necessary in order to make an effective adjustment.

When the option Offset is selected, the following screen is shown:

INFORMATION
The flow rate must be zero
Press any key

CAL. OFFSET
When the flow rate is stable press OK
0.03 m3/h

When the flow rate is stable, press the key (Enter) and the instrument will save the value.

INFORMATION
Offset calibrated
Press any key

7.5 Outputs

This screen allows to program the four outputs of the instrument: Relay 1, Relay 2, pulses and analog output (4-20 mA).

7.5.1 Relay 1 and relay 2



OUTPUTS E/L
▶ Relay 1
Relay 2
Pulses
4-20 mA

By selecting one of the two relay outputs, next screen appears with the options which allow to assign the relay to a function.

RELAY 1 E/L
▶ Alarm
Empty pipe
Negative flow rate

7.5.1.1 Alarm

If Alarm is selected, we have access to program the flow rate at which the relays will change its status and to the level of hysteresis. By level of hysteresis we understand the difference between activation and deactivation of the output. To avoid that an alarm output is continuously moving from activate to deactivate status, we must program the points of connection and disconnection.



Example

If the activation point is programmed to 100 m³/h and the deactivation point is programmed to 90 m³/h, when the flow rate is zero the output will be deactivated. When the flow rate reaches a value of 100 m³/h the output will be activated until the flow rate falls below 90 m³/h.

If we program an activation point of 90 m³/h and a deactivation point of 100 m³/h, when the flow rate is zero the output will be activated. When the flow rate reaches a value of 100 m³/h the output will be deactivated until the flow rate falls below 90 m³/h.

7.5.1.2 Empty pipe


In this case, the relay will change its status when the flowmeter detects empty pipe.

7.5.1.3 Negative flow

The relay will change its status when the flow rate changes its sign.


7.5.2 Pulse output

This output allows to connect the converter to a PLC or remote totalizer. The number of pulses per unit of volume can be programmed. The following parameters can be selected.



7.5.2.1 Pulse output configuration

It allows to choose between unidirectional and bidirectional.




If “Unidirectional” is chosen, the output will give pulses proportional to flow rate when the flow rate is positive, and will not give them when the flow rate is negative.

If “Bidirectional” is chosen, the output will give pulses proportional to flow rate in both flow directions.

7.5.2.2 Units

First volume units for which we want to get a number of pulses are selected.




7.5.2.3 Pulses

Then the pulses per unit of volume that we will obtain at the output are selected.



7.5.2.4 Duty Cycle


With the duty cycle width or percentage of time the pulse will be active during each cycle can be determined.



Active pulse is when the NPN transistor at the output (see 2.2.5) is ON.


7.5.3 Analog output

The flow rate corresponding to 4 mA and 20 mA can be programmed and the calibration for these two values can be made as well.



7.5.3.1 4-20 mA output configuration

It allows to choose between unidirectional and bidirectional.




If "Unidirectional" is chosen, the analog output will have a value proportional to the flow rate when positive, and it will provide always 4 mA when negative.

If "Bidirectional" is chosen, the analog output will have a value proportional to the flow rate for both positive and negative values.

7.5.3.2 Programming of the 4-20 mA output

Flow rate values equivalent to each current are entered directly.





Programming a flow rate value for 20 mA higher than the one for 4 mA, the loop current changes from 4 to 20 mA as the flow increases.

Otherwise, programming a flow rate value for 20 mA lower than the one for 4 mA, the current loop will change from 20 to 4 mA as the flow increases.

7.5.3.3 Current calibration for 4 and 20 mA


The MX4 converter is delivered with the current output already calibrated. If you want to correct a derive of the 4 or 20 mA current values because they do not coincide with the ammeter used, it can be done by pressing the keys (Down / Left) and (Up) to increase or decrease the current respectively in each case. The values shown on the screen are reference levels. When one of this data is confirmed, the MX4 will take the current value shown on the ammeter as a reference.



Before making a current calibration, be sure that the ammeter used for that is showing the real measure.

7.6 Working screen


Flow rate, totalizer, liquid velocity or flow rate and totalizer screens can be programmed as a default. Thus, the converter presents this screen when a power failure occurs or when returning from the installation or programming menu.



7.7 Totalizer

In this screen you can configure the totalizer operation mode depending on the flow direction. Thus, the value indicated by the totalizer will always be true regardless of the application where the flowmeter is installed.


The first screen after selecting "Totalizer" is the following:



In this screen you can choose the flow direction for which you want to configure the action that the totalizer will do.

Positive flow is defined as the one that appears unsigned on the default screen, and negative flow the one that appears with a — sign on the default screen.

Once the flow rate direction is chosen, a screen with the different actions is shown:



If "Null" is selected, the totalizer remains unchanged. If "Increase" is selected, the totalizer will add the amount of fluid passing through the flowmeter, and if you select "Decrease", the totalizer will subtract that amount.

Examples:

- a) Installation in which for a time the product flows through the pipe and after that a cleaning process in reverse direction is performed. The programming will be:
Positive flow rate action: Increase
Negative flow rate action: Null
- b) Installation in which for a time the product flows through the pipe to a tank, and after that a quantity of the product comes back in the opposite direction. The programming will be:
Positive flow rate action: Increase
Negative flow rate action: Decrease
The totalizer will indicate the volume of product that there is in the tank.

- c) Installation in which for a time a first product flows through the pipe, and after that a second product flows in the opposite direction. The programming will be:
- Positive flow rate action: Increase
- Negative flow rate action: Increase
- The totalizer will indicate the volume corresponding to the sum of both products.

Note: To reset the totalizer, go to chapter 5 (page 27).

7.8 Modbus


This option is only implemented in some devices.

It allows to configure the needed parameters to establish a Modbus RTU communication with the instrument.

Detailed information on this point could be found in the R-IT-MX4COM instructions manual, that can be downloaded from the Tecfluid S.A. website.


8 SERIAL NUMBER

In this section the converter serial number is shown.




9 SOFTWARE VERSION




From the main menu, if "Software version" is selected, the screen will show this data and the corresponding date.



10 WORKING SCREEN

When exiting the menu, the display shows the default screen. To scroll between the three operating screens, press the key (Down / Left) or (Up).





11 STARTING CURRENT

It may happen that the chosen power supply can not provide the required current for the equipment to operate properly. In this case an information message will appear indicating this situation.

INFORMATION

Invalid power supply
Please check
instructions manual

12 ASSOCIATED SOFTWARE WINSMETER MX4

Most of the steps in the preceding paragraphs can be done by means of the device associated software Winsmeter MX4, which allows working in a more comfortable and intuitive way.

Such software can be downloaded from the “Downloads” section of the Tecfluid S.A. website www.tecfluid.com/downloads

12.1 USB cable connection and drivers installation

Extract the files from the winsmeterMX4.zip to a new system folder.

Execute the Setup.exe file and follow the steps for the installation.


In order to connect the converter to a computer an USB cable is required. This cable is type A at one end and type B at the other, and it is readily available on the market.



The ends of the cables can be seen in the picture.

The first step to do the connection is to open the rear cover of the electronic converter.


The USB connector is located below the right terminal strip.



Connect the USB cable at one end to the converter and at the other to the computer where the software is installed.

Power on the electronic converter.


Execute the program WinsmeterMX4 following the sequence Start – Programs – Tecfluid S.A. - WinsmeterMX4.



12.2 Port connection

In the "Port" section, choose the appropriate port for the converter. This will appear with the name of the port followed by MX4 and its serial number. Then click "Open".

Once the port is open, the button "Open" in the "Installation" and "Programming" sections activates.




12.3 Access to installation and programming

In order to change the data contained in the "Install" tab, you must enter a password.


The default password is **install**, and it can be changed using the boxes on the right of the "Installation" section.

Likewise, to change the data contained in the "Programming" tab it is necessary to enter the password which by default is **program**. This can be changed using the boxes on the right of the "Programming" section.



Once the password is written, press "Enter" or "Open", and the installation or programming tab will open. At the bottom of each section the text "Installation tab open" or "Programming tab open" will be displayed.


To enter the Installation window, just click the corresponding tab.



In the installation window the parameters that adapts the converter to a sensor and to a certain installation can be configured.

To transfer data to the MX4 converter, press the "Send" button. The message "Saving program" will appear for two seconds in the converter screen. The installation data will be stored in the memory of the converter.

Likewise, to enter into the programming window, just click the corresponding tab.



Changing the parameters of this screen the different functions of the equipment can be programming.

As in the previous paragraph, to program this data to the MX4 converter, press the "Send" button. The message "Saving program" will appear for two seconds in the converter screen. The programming data will be stored into the memory of the converter.

12.4 Datalogger


| Date | Time | Flow rate (l/h) | Velocity (m/s) | Total (l) | Loop current (mA) |
|------------|----------|-----------------|----------------|-----------|-------------------|
| 18/01/2017 | 12:58:37 | 1293.8 | 4,58 | 195,8 | 18,6 |
| 18/01/2017 | 12:58:38 | 1293.8 | 4,58 | 196,4 | 18,6 |
| 18/01/2017 | 12:58:39 | 1293.8 | 4,58 | 197,0 | 18,6 |
| 18/01/2017 | 12:58:40 | 1293.8 | 4,58 | 197,8 | 18,6 |
| 18/01/2017 | 12:58:41 | 1293.8 | 4,58 | 198,4 | 18,6 |
| 18/01/2017 | 12:58:42 | 1293.7 | 4,58 | 199,2 | 18,6 |
| 18/01/2017 | 12:58:43 | 1293.9 | 4,58 | 199,7 | 18,6 |
| 18/01/2017 | 12:58:44 | 1293.6 | 4,58 | 200,3 | 18,6 |
| 18/01/2017 | 12:58:45 | 1293.6 | 4,58 | 201,1 | 18,6 |
| 18/01/2017 | 12:58:46 | 1293.5 | 4,57 | 201,7 | 18,6 |
| 18/01/2017 | 12:58:47 | 1293.5 | 4,57 | 202,3 | 18,6 |
| 18/01/2017 | 12:58:48 | 1293.5 | 4,57 | 203,0 | 18,6 |
| 18/01/2017 | 12:58:49 | 1293.6 | 4,58 | 203,6 | 18,6 |
| 18/01/2017 | 12:58:50 | 1293.5 | 4,57 | 204,4 | 18,6 |
| 18/01/2017 | 12:58:51 | 1293.6 | 4,58 | 205,0 | 18,6 |
| 18/01/2017 | 12:58:52 | 1293.6 | 4,58 | 205,5 | 18,6 |

In this window the process of the different variables of the equipment can be registered in a file.

The time between samples, as well as the start and end time of the record can be selected.


When the "Register" button is pressed, the screen that allows to name the file and select its location appears.

The created file has CSV format, which can be viewed directly with a spreadsheet.



12.5 Visualization

When the communication with the computer port is established (see section 12.2), the tab "Visualization" opens. This tab lets you view real-time flow rate, totalizer and velocity values, as well as the current value of the analog output and the status of the relay outputs.



It is an intuitive tool to verify that the instrument has been installed and programmed correctly.


By means of the "Record" button, you can store data in different computer files, which can then be processed by other software.

12.6 Firmware updates


New firmware updates can be published in the website. These updates contain improvements or bug fixes that make the equipment operates at best conditions.

The updates can be downloaded from the “Downloads” section of the Tecfluid S.A. website www.tecfluid.com/downloads


To update the equipment, go to menu “Firmware” - “Update”, and a screen with the button “File” will appear. Pressing this button system can be accessed. The downloaded file has to be searched there.



Once the file is selected, press the “Program” button. A message “Programming device” will appear.



The process takes about 90 seconds, after which the message “Device programmed” will appear.



From this moment, the converter MX4 already has the new version of Firmware.

13 TECHNICAL CHARACTERISTICS

Accuracy

$\pm 3.5\%$ reading value for $v > 0.4$ m/s

$\frac{\pm 1.75}{v \text{ (m/s)}}$ reading value for $v \leq 0.4$ m/s

Repeatability

$\pm 0.15\%$ reading value ± 0.75 mm/s

Velocity range

0.2 ... 10 m/s

Temperature

Process temperature: -20°C ... $+120^{\circ}\text{C}$

Ambient temperature: -20°C ... $+70^{\circ}\text{C}$

Minimum conductivity

20 $\mu\text{S/cm}$

Power supply

90 ... 265 VAC 50, 60 Hz

Power consumption: ≤ 5 VA

12 ... 48 VDC

Power consumption: ≤ 5 W

Analog output

4-20 mA. Active or passive. galvanically isolated from the power supply.

Pulse output

Optoisolated. NPN bipolar transistor. V_{max} : 30 VDC. I_{max} : 30 mA.

Maximum frequency : 5000 Hz

Minimum frequency : 0.01 Hz

Relay outputs

2 relay with potential free contacts.

Contact characteristics:

Maximum voltage : 250 VAC

Maximum current : 8 A

Maximum power : 500 VA

Totalizer

N. of digits: 8 (2 decimals)**

Digit size: 8 mm

Reset: by means of keyboard

Flow rate indication

N^o of digits: 5 (up to 2 decimals configurable)**

Digit size: 11 mm

** When the available digits are full and the integers overflow a decimal is automatically lost.

Liquid velocity indication

N° of digits: 5 (2 decimals)

Digit size: 11 mm

General characteristics

Sensor materials:

| Body | Head | Electrodes |
|--------------------------|------|--|
| EN 1.4404 (AISI 316L) | PVDF | Hastelloy C22 AISI 316L Titanium |
| PVDF | PVDF | Zirconium Tantalum |

MX4 converter material: Coated aluminium

Ingress protection:

Sensor: IP68, 10m H₂O

MX4 converter: IP67

Maximum cable length (remote version) : 150 m

Communication protocols (optional)

Modbus RTU

HART

Detailed information on these protocols can be found in the R-IT-MX4COM instructions manual, that can be downloaded from Tecfluid S.A. website.

14 MAINTENANCE

Sensor:

Electrode cleaning is recommended in installations where significant build ups or sedimentation occur.

Cleaning can be done with detergent liquids and cleaning brushes of medium hardness.

Converter:

No special maintenance is required.

For external cleaning, a humid cloth can be used, and if necessary with a little neutral soap. Solvents or other aggressive liquids which could damage the housing material should not be used.

14.1 Fuse

In the event that the fuse blows, this should be replaced with a slow blow "T" fuse, size Ø5 x 20 mm and with the value indicated on the label inside the equipment.

15 SAFETY INSTRUCTIONS

The series FLOMAT flowmeters are in conformity with all essential requirements of all EC directives applicable to them:

| | |
|------------|---|
| 2014/35/EU | Low voltage directive (LV) |
| 2014/30/EU | Electromagnetic compatibility directive (EMC) |
| 2012/19/EU | Waste electric and electronic equipment (WEEE). |
| 2011/65/EU | Restriction of the use of certain hazardous substances in electrical and electronic equipment (ROHS). |



The declarations UE of conformity can be downloaded from the section “Download” of the Tecfluid S.A. website. www.tecfluid.com

15.1 Pressure equipment directive

Series FLOMAT of flowmeters, due to their size, are not subject to conformity assessment, are considered outside the scope of the directive and therefore they have not the CE mark according to pressure directive. These devices are subject to applicable sound engineering practice (SEP).



This equipment is considered as being a pressure accessory and **NOT** a safety accessory as defined in the 2014/68/EU directive, Article 2, paragraph 4.


15.2 Certificate of conformity TR CU (EAC marking)

Tecfluid S.A. have subjected the series FLOMAT of flowmeters to a certification procedure according to the technical regulations of the Customs Union of the Eurasian Economic Union (EEU).



This Certificate is an official document confirming the quality of production with the standards on the territory of the Customs Union, particularly regarding safety requirements and electromagnetic compatibility.

16 DIMENSIONS




FLOMAT-FX (R 2 ¼)

| DN | A | FM * |
|---------------|-------|------|
| 40 ... 450 | 113,5 | 328 |
| 500 ... 1000 | 218,5 | 433 |
| 1200 ... 2000 | 368,5 | 583 |

* FM is the minimum length to remove the instrument from the pipe

(All dimensions in mm)




FLOMAT-FX (TF flange and standards)

| DN | A | FM * |
|---------------|-------|------|
| 40 ... 450 | 113,5 | 328 |
| 500 ... 1000 | 218,5 | 433 |
| 1200 ... 2000 | 368,5 | 583 |

* FM is the minimum length to remove the instrument from the pipe

(All dimensions in mm)




FLOMAT-FX (remote converter version)

| DN | A | FM * |
|---------------|-------|------|
| 40 ... 450 | 113,5 | 328 |
| 500 ... 1000 | 218,5 | 433 |
| 1200 ... 2000 | 368,5 | 583 |


* FM is the minimum length to remove the instrument from the pipe

(All dimensions in mm)

MX4 REMOTE CONVERTER (wall mounting)



MX4 REMOTE CONVERTER (pipe mounting)




17 TROUBLESHOOTING

| Problem | Probable cause | Solution |
|--|--|--|
| The screen shows empty pipe | Pipe is empty | Make sure that the pipe is completely full, for example, installing the flowmeter in a vertical pipe with upwards flow |
| | The functional earth is not connected | Connect the functional ground of the flowmeter to a metallic point of the installation in contact with the liquid |
| | Isolation of the electrodes | Clean the sensor electrodes |
| | Electrode cable disconnected | Connect the cable between the sensor and the electronic converter |
| | Liquid with very low conductivity | The flowmeter is not adequate for the application |
| The flow rate is unstable | Dirt on the electrodes | Clean the sensor electrodes |
| | The product contains air or non-conductive particles in suspension | Verify that the flowmeter is adequate for this application |
| | The instrument is misaligned | Align according to point 5.2 on page 14 |
| The flow rate displayed is 0 | Coil cable disconnected | Connect the cable between the sensor and the electronic converter |
| | The flow rate is smaller than programmed as CUT OFF | Decrease the value of the cut off (see page 35) |
| | The instrument is mounted perpendicularly to its correct position | Install the instrument correctly (see point 5.2 on page 14) |
| The instrument displays a value when there is not flow | The sensor is damaged due to electrodes corrosion | Electrode material not adequate for the liquid |
| | The functional earth is not connected and the empty pipe option is OFF | Connect the functional ground of the flowmeter to a metallic point of the installation in contact with the liquid |
| | The instrument is mounted perpendicularly to its correct position | Install the instrument correctly (see point 5.2 on page 14) |

| Problem | Probable cause | Solution |
|---|---|---|
| The displayed flow rate is higher than expected | The electrodes are immersed but the pipe is not completely full | Make sure that the pipe is completely full, for example, installing the flowmeter in a vertical pipe with upwards flow. |
| Display is blank | Blown fuse | Change the fuse |
| | Not enough current from the power supply | Change the power supply |
| The analog output gives always 4 mA or 20 mA | Current output range not properly programmed | Program the range properly (see page 39) |
| The analog output gives always 0 mA | Cable disconnected | Check the cable connection |
| The invalid current message appears | Insufficient current from the power supply | Change the power supply |

ANNEX A

Flow rate diagram



WARRANTY

Tecfluid S.A. guarantee all the products for a period of 24 months from their sale, against all faulty materials, manufacturing or performance. This warranty does not cover failures which might be imputed to misuse, use in an application different to that specified in the order, the result of service or modification carried out by personnel not authorized by Tecfluid S.A., wrong handling or accident.

This warranty is limited to cover the replacement or repair of the defective parts which have not damaged due to misuse, being excluded all responsibility due to any other damage or the effects of wear caused by the normal use of the devices.

Any consignment of devices for repair must observe a procedure which can be consulted in the website www.tecfluid.com, "After-Sales" section.

All materials sent to our factory must be correctly packaged, clean and completely exempt of any liquid, grease or toxic substances.

The devices sent for repair must enclose the corresponding form, which can be filled in via website from the same "After-Sales" section.

Warranty for repaired or replaced components applies 6 months from repair or replacement date. Anyway, the warranty period will last at least until the initial supply warranty period is over.

TRANSPORTATION

All consignments from the Buyer to the Seller's installations for their credit, repair or replacement must always be done at freight cost paid unless previous agreement.

The Seller will not accept any responsibility for possible damages caused on the devices during transportation.



Tecfluid S.A.

Narcís Monturiol 33
08960 Sant Just Desvern
Barcelona
Tel: +34 93 372 45 11
Fax: +34 93 473 08 54
tecfluid@tecfluid.com
www.tecfluid.com

Quality Management System ISO 9001 certified by



Pressure Equipment Directive certified by



ATEX European Directive certified by



HART is a trademark of FieldComm Group™

The technical data described in this manual is subject to modification without notification if the technical innovations in the manufacturing processes so require.