

Instructions manual

Series M21 Variable area flowmeter



HART
COMMUNICATION FOUNDATION



PREFACE

Thank you for choosing a product from Tecfluid S.A.

This instruction manual allows the installation, configuration, programming and maintenance. It is recommended to read it before using the equipment.

WARNINGS

- This document shall not be copied or disclosed in whole or in any part by any means, without the written permission of Tecfluid S.A.
- Tecfluid S.A. reserve the right to make changes as deemed necessary at any time and without notice, in order to improve the quality and safety, with no obligation to update this manual.
- Make sure this manual goes to the end user.
- Keep this manual in a place where you can find it when you need it.
- In case of loss, ask for a new manual or download it directly from our website www.tecfluid.com Downloads section.
- Any deviation from the procedures described in this instruction manual, may cause user safety risks, damage of the unit or cause errors in the equipment performance.
- Do not modify the equipment without permission. Tecfluid S.A. are not responsible for any problems caused by a change not allowed. If you need to modify the equipment for any reason,

TABLE OF CONTENTS

SERIES M21

1	INTRODUCTION	6
2	WORKING PRINCIPLE	6
3	RECEPTION	8
4	INSTALLATION	8
4.1	Valves	8
4.2	Filters	8
4.3	Straight pipe sections	8
5	OPERATION	9
5.1	Gas flow measurement	9
5.2	Gas damping mechanism	10
5.3	Liquid flow measurement	11
6	RCA / RCD FLOW REGULATORS	12
6.1	Regulation curves	13

AMD LIMIT SWITCH

7	INTRODUCTION	15
8	OPERATION	15
9	MOUNTING THE LIMIT SWITCH IN AN EXISTING EQUIPMENT	16
9.1	Kit contents	16
9.2	Preparing the kit	16
9.3	Assembling the AMD kit	17
9.4	Switching point adjustment	18
9.5	Electrical connection	19
9.6	Mounting	19
10	ELECTRICAL CONNECTION	19

TH6 TRANSMITTERS

11	INTRODUCTION	20
12	MODELS	20
12.1	TH6	20

12.2	TH6H	20
13	ELECTRICAL CONNECTION	20
13.1	Power supply and analog output	21
14	4-WIRE CONNECTION	21
15	HART TRANSMITTERS	22
15.1	Additional functions with HART communication	22
15.2	HART communication characteristics	22
16	"WRITE PROTECT"	23
17	MAINTENANCE	24
17.1	Series M21	24
17.2	M21 with damping system	25
17.3	Potential problems with the metering tube	25
17.3.1	Jammed float	25
17.3.2	Lack of magnetic field	26
17.3.3	Damaged calibrated orifice and/or float	26
17.4	Potential problems with the indicator housing	26
17.4.1	The indicator pointer rubs on the reading scale	26
17.4.2	Deviation of the zero on the scale	26
17.5	RCA regulator maintenance	27
17.6	RCD regulator maintenance	28
17.7	AMD limit switch maintenance	29
17.7.1	Electrical verification	29
17.8	TH6 transmitter maintenance	29
18	TECHNICAL CHARACTERISTICS	30
18.1	Series M21	30
18.2	AMD limit switch	31
18.3	TH6 transmitter	31
18.3.1	Power supply	31
18.3.2	Outputs	31
18.3.3	General characteristics	31

19	SAFETY INSTRUCTIONS	32
19.1	Pressure equipment directive	32
19.2	Certificate of conformity TR CU (EAC marking)	32
20	ADDITIONAL INSTRUCTIONS FOR THE ATEX VERSION	33
20.1	Non-metallic parts	33
20.2	Connecting conductive parts to earth	33
20.3	AMD limit switch	34
20.4	TH6 transmitters	34
20.5	Marking	35
21	FLOW RANGES	36
22	DIMENSIONS	37
23	ATEX CERTIFICATE	42
24	DECLARATIONS OF CONFORMITY ACCORDING TO ATEX	45

SERIES M21

1 INTRODUCTION

The series M21 are flowmeters for liquids, gases and steam.

They are very robust instruments prepared to work under extreme conditions.

They have local flow rate indication by means of magnetic coupling, with scales calibrated in l/h, m³/h, kg/h, t/h, %, etc.

They can fit switches or electronic transmitters that allow to detect a specific flow rate and provide a flow rate signal to a remote device.

2 WORKING PRINCIPLE

Based on variable area principle.


The flowmeter consists of a measuring tube and a float inside it. The flow pushes the float to an equilibrium point. The area obtained between the float and the tube is proportional to the flow rate.

The equilibrium point depends on:

- E = Force of the fluid flow
- F_f = Weight of the float
- A_l = Free area of flow


where:

($A_l = A_o$, calibrated orifice area, - A_f , float area)




M21 models always work in a vertical position with upwards flow.

The equilibrium point is determined by considering the fluid force and the float weight.



The M21-H... models have horizontal inlet and outlet, and optionally they can be supplied with a regulating valve on the inlet.



3 RECEPTION

The series M21 flowmeters are supplied conveniently packaged for their protection during transportation and storage, together with their instructions manual for installation and operation.

The instruments are supplied tested in our calibration rigs, ready for installation and service.

Before installing the flowmeter, remove all the blocking elements.

With the instrument in its working position, move the float and check that the indicating needle moves all over the scale and returns to zero.

4 INSTALLATION

Flowmeters models M21 must be installed in a completely vertical position and with upwards flow direction.



It is important that the position is completely vertical given that deviations of about 5° can produce errors of about 8-10% of the readings.

4.1 Valves

If the fluid to be measured is a liquid, it is recommended to install a regulating valve before the flowmeter (see point 5.3), or to use a M21-H... model, which already includes a valve on the inlet.

For gas flow measurement, the valve position will depend on the calibrating pressure (see point 5.1).



Valves should always be opened slowly to avoid water hammers.

4.2 Filters

The installation of a filter before the instrument is important, this will avoid possible obstructions and breakdowns in the measuring system.

The filter mesh should be maximum 200 µm.

In case of having abundant magnetic particles in suspension, it is necessary to mount a magnetic filter on the inlet of the instrument to avoid the accumulation of particles around the float, which would make it to jam.

4.3 Straight pipe sections

In order to have stable readings, it is essential to avoid turbulences. To do this, it is necessary to install the instrument in a straight pipe section. This section should have the same inner diameter as the flowmeter. The required minimum distances upstream and downstream of the sensor are the following:

Upstream	5 DN
Downstream	3 DN

These distances must be free of elements that can disturb the flow profile, such as elbows, diameter changes, valves, etc.

5 OPERATION

Once the meter is installed, the regulating valve should be opened slowly. The fluid flow will move the float which, by means of magnetic coupling, moves the indicating needle.



Any variations of working conditions with respect to those when calibrated can induce reading errors. The calibration working conditions are indicated on the instrument's dataplate.


5.1 Gas flow measurement

The working pressure and temperature are of maximum importance for correct gas measurement as they directly affect the scale readings.

For example, if a meter is calibrated at 2 bar gauge and the working pressure is 1 bar gauge there will be an error of about 22%.

In the same way, if working temperature does not match calibrating temperature, errors will be induced in the flow rate readings.

In applications of gas flow measurement where the calibrating pressure of the instrument corresponds to the inlet pressure, being higher than the atmospheric pressure, the regulating valve must be installed downstream of the flowmeter. Thus, it is ensured that the instrument works at calibrating pressure and a back pressure that keeps the float in equilibrium is obtained.



NOTE: Scheme valid for gas flow measurement applications with a pressure higher than atmospheric. For gases at atmospheric pressure, turn valves upside down.

The flow should be adjusted by means of the regulating valve, while keeping the shut off valve fully open.

If the regulation is done using the shut off valve, in open circuits or at low gas flow in the meter, the gas will expand which will sharply diminish its density, providing very serious reading errors.

If the flow is regulated by the shut off valve, the float usually experiences an oscillating movement which produces a shut off action until sufficient pressure is gained to overcome its weight. The sudden fall of pressure, when the gas escapes, will make it fall. This cycle is repeated generating an oscillating measurement (resonance).

In applications where the gas outlet is at atmospheric pressure, install the regulating valve upstream of the flowmeter if the flowmeter was calibrated at atmospheric pressure. The shut off valve is then installed downstream of the flowmeter and it should be fully open.

The valve opening procedure should be as following:

- With the regulating valve closed, fully open the shut off valve.
- Gradually open the regulating valve until the desired flow rate.

And for closing:

- Close the regulating valve gradually until zero flow rate.
- Fully close the shut off valve to isolate the flowmeter.

Operating in a different way may involve water hammers that can damage the meter reading or generate instabilities.




REMARK: For gas applications at a pressure higher than the atmospheric pressure, it is recommended to use the M21 models without valve and install a separate valve at the outlet of the flowmeter.


M21-H... models do not allow their own valve to be mounted at the outlet, they are only available with valve at the inlet.

5.2 Gas damping mechanism

M21 1/4" damping mechanism



M21 1/2" and 3/4" damping mechanism



When measuring low pressure gas flow with AISI 316L floats, oscillation of the float often occurs, which makes it very difficult to read the flow rates. In these cases it is recommended to install a damper in the instrument.


The damper consists of a piston mounted inside a cylinder, closed at its lower end. The compression forces of the gas absorb the floats oscillations, maintaining it stable in the reading point.



Close the valves during work stops at the end of the working day in order to avoid sudden surges when started up. If the float hits the stops sharply this could cause damage to the meter.

5.3 Liquid flow measurement

When measuring liquids the regulating valve should be installed as shown in the following figure.



Being the shut off valve partially open, open the regulating valve slowly until the needle of the indicator housing shows a low flow rate. Then also open the shut off valve slowly in order to get rid of the air and then progressively to fully opened.

The required flow rate is then regulated by using the regulating valve.


Close the valves during work stops at the end of the working day in order to avoid sudden surges when started up. If the float hits the stops sharply this could cause damage to the meter.

6 RCA / RCD FLOW REGULATORS

The M21 series flowmeters are built to incorporate the RCA and RCD regulators, that keep a constant flow rate when the operating pressure at the inlet or outlet are not constant.

In applications for gases, the RCA model is used in installations where inlet pressure is variable and outlet pressure or counter pressure is constant, while model RCD is used in installations where the inlet pressure is constant and outlet pressure or counter pressure is variable.

In liquids, model RCA is the commonly used.




The differential pressure between P_0 and P_2 should always be higher than 350-450 mbar depending on the model. This differential pressure is calculated for the proper operation of the flow rate regulator.

6.1 Regulation curves

The flow curves show the relationship between the inlet pressure P_0 and the counter pressure P_2 in the RCA regulator.

The different flow rates are adjusted by means of the regulating valve of the flowmeter. The counter pressure P_2 , in these cases, corresponds to the atmospheric pressure.




P_0 = inlet pressure RCA regulator (low flow)

The dotted line shows the variation of flow without the action of the constant flow regulator.


With constant flow regulator, variations of 100% in the inlet pressure P_0 involve variations of flow of less than 1%.

Q air (Nl/h)



P_0 = inlet pressure RCA regulator (high flow)

Q air (Nl/h)



P_0 = outlet pressure RCD regulator (low flow)

AMD LIMIT SWITCH

7 INTRODUCTION

The AMD limit switch can be used to generate an alarm or an operation when the flow rate that the instrument is measuring reaches a preset value on the scale plate.


The AMD limit switch consists of a NAMUR slot type inductive sensor, that is actuated by a vane. Given that there is no physical contact in the operation, the limit switch has no influence on the indicator needle movement.

An instrument can be equipped with one or two sensors, depending on the number of points to be detected. A NAMUR amplifier with a relay output can be supplied as an option.

8 OPERATION

The indicator needle moves together with the vane mounted on its shaft. When the vane enters into the slot of the sensor, the limit switch changes its state.

The sensor is mounted on a support which includes a needle that indicates the switching position. The needle, that is below the scale plate, can be seen through the scale slot.



9 MOUNTING THE LIMIT SWITCH IN AN EXISTING EQUIPMENT

When the AMD limit switch is to be fitted to an existing device, please follow these steps.

9.1 Kit contents

The kit contains the following elements:


AMD kit		
Quantity	Material	Position
1	AMD limit switch circuit	1
2	Self tapping screw DIN7982 B-2,2 x 9,5 N°2 A2	2
1	AMD vane	3
1	Self tapping screw DIN7982 B-2,2 x 9,5 N°2 A2	4
2	Gasket	5
2	Cable gland IP68	6
2	Cable gland blanking plug	7

In the kits, the gaskets (5) and the blanking plugs (7) are not provided as loose parts. They are incorporated in the cable glands (6).

9.2 Preparing the kit

To access the AMD, the cover has to be removed, unscrewing the four screws M4.

Slide the scale plate in the direction indicated in the figure, until it is released from the slot.




Ensure that the gaskets (5) are placed in the thread of the gland (6). If not, they should be placed. Remove the plugs from the indicator box with a flat screwdriver and replace them by the two cable glands.




The cable glands that are not expected to be used should be left with the blanking plug (7) placed to preserve watertight.

9.3 Assembling the AMD kit

Slide the circuit (1) into the slot until it stops, and then screw it as shown in the figure.



Place the vane (3) in the position shown in the figure. The height on the shaft should be such that when the vane passes through the sensor slots, remains centered without touching them. Tighten the screw (4) holding the vane against the shaft.




9.4 Switching point adjustment

At the bottom of the switching needle, the fixing nuts of the switching points can be found.

To move the switching point, the fixing nuts have to be slightly loosen without removing the scale plate (see figure on the next page). After that, place the switching point at the required scale value, and fix it with the nuts.

As standard, when the instrument has only one AMD, it is configured as a minimum limit switch.




9.5 Electrical connection

Do it according to section 10.

9.6 Mounting

Slide the scale plate into the slot until it stops as shown in the figure. Mount the cover with the four screws M4.



10 ELECTRICAL CONNECTION

To access the electrical connections, the scale cover must be removed. To do this, slide it to the left in the slot until it is free. For the electrical connection, the instrument is provided with a four terminal connector.


For the electrical installation it is recommended to use multiple conductor cables with sections of 0.25 or 0.5 mm², in order to make it easier to connect.

Before starting the installation, check that the cable glands are the right size for the cables to be used, this will guarantee the instrument will stay watertight. The M12x1.5 cable glands used are for cables with outside diameters between 2.5 mm and 6.5 mm.

Peel the outside insulation to free the inner cables. It is recommended to tin the ends of the wires to avoid loose ends. Pass the cables through the cable glands and screw down in the corresponding positions of the terminal strip. Once the wiring is finished make sure that the cables are well gripped by the cable glands to maintain the degree of protection.

The cable glands must be always closed. Entry of dust or some types of vapours can damage the internal system of bearings and therefore the equipment.

To gain access to the terminal block, the scale plate must be removed. To do this, slide it to the left through the slot until released.



TH6 TRANSMITTERS


11 INTRODUCTION

Transmitters TH6 are electronic position transducers with a microprocessor. The instrument uses the Hall effect to capture the field of a magnet. This signal, after the microcontroller processing, is converted into a current signal of 4-20 mA in a 2-wire loop. This signal is proportional to the flow rate.

12 MODELS

12.1 TH6

It is a 4 to 20 mA transmitter proportional to flow rate. 4 mA corresponds to beginning of the scale. 20 mA corresponds to full scale. Between the beginning of the scale and the first point of the scale the analog output is constant at 4 mA (see figure), to avoid false readings of flow rate.



12.2 TH6H

It is a TH6 transmitter that incorporates HART™ protocol compatibility. With this protocol the user can change the measuring range of the 4-20 mA loop, and data like flow rate, with its associated measuring units.

13 ELECTRICAL CONNECTION

For the electrical connection, the transmitter has two screw terminals.

For the electrical installation it is recommended to use multiple conductor cables with individual cable sections in the order of 0.25 to 0.5 mm² in order to make it easier to connect.

A twisted pair wiring should be used to avoid electrical interferences in the 4-20 mA loop. In some instances, shielded cable may be necessary.

Before starting the installation, check that the cable glands are the right size for the cables to be used, this will guarantee the instrument will stay watertight. The M12x1.5 cable glands used are for cables with outside diameters between 2.5 mm and 6.5 mm.

Peel the outside insulation to free the inner cables. It is recommended to tin the ends of the wires to avoid loose ends. Pass the cables through the cable glands and screw down in the corresponding positions of the terminal strip. Once the wiring is finished make sure that the cables are well gripped by the cable glands to maintain the degree of protection.

The cable glands must be always closed. Entry of dust or some types of vapours can damage the internal system of bearings and therefore the equipment.




Before connecting the power supply, you must be sure that the supply voltage is the correct for the installation.



The power supply voltage is indicated on the label of the transmitter.


13.1 Power supply and analog output

The connection is made in the terminal block (see figure). The positive terminal of the power supply is connected to the position (+) and the positive terminal of the load in the position (-). The negative terminals of the power supply and the load are connected together. The instrument works in a 2-wire system, that is, the supply and signal line are the same. It is recommended to use a twisted pair wiring or shielded cable to avoid interferences in the current loop.



14 4-WIRE CONNECTION

If Direct Current power supply for the transmitter is not available in the installation, it will be necessary to incorporate an additional power supply as in the following figure.



15 HART TRANSMITTERS

The TH6H transmitters have a modem for HART communication.

TH6H transmitters are fully compatible with the **HART Server** software from HART Communication Foundation.




Tecfluid S.A. do not guarantee that the TH6H transmitter is compatible with the different servers on the market.

When connecting the transmitter, an external resistor (R ext.) should be included. Its minimum value needs to be 200 Ω, and the maximum value depends on the power supply as follows:

$$R(\text{Ohm}) = \frac{V - 14}{20 \cdot 10^{-3}}$$

In this case the power supply voltage needs to be 18 VDC minimum. In order to establish HART communication, it is necessary to connect a terminal or PC with a HART modem, in one of the points indicated in the following figure.



15.1 Additional functions with HART communication

By means of the implemented commands, the user can obtain the following information:

- Flow rate value in the scale units
- Totalizer value (even if the equipment does not have a display).
- Reset or writing of a totalizer value.
- Change of beginning and end of scale of the current loop.
- Possibility of writing tags and messages into the instrument.

15.2 HART communication characteristics

The detail of the characteristics with respect to the HART communication are available in the corresponding "Field Device Specification" document.

Summary of the main communication characteristics:

Manufacturer, Model and Revision	Tecfluid S.A., TH6H, Rev. 0
Device type	Transmitter
HART revision	6.0
Device Description available	No
Number and type of sensors	1
Number and type of actuators	0
Number and type of host side signals	1, 4 – 20 mA analog
Number of Device Variables	2
Number of Dynamic Variables	1
Mappable Dynamic Variables	No
Number of Common Practice Commands	5
Number of Device Specific Commands	0
Bits of Additional Device Status	12
Alternative working modes?	No
Burst mode?	No
Write Protection?	Yes


Electrical characteristics referred to the analog loop and communications:

Reception impedance:

Rx	>	3,3 M Ω
Cx	<	1000 pF

16 “WRITE PROTECT”

The instrument has a jumper that can be used to avoid changes in the configuration. When the jumper is connected the instrument can be configured via HART. When the jumper is removed, “Write Protect” is activated for HART, thus avoiding any changes in the configuration (see figure).



17 MAINTENANCE

17.1 Series M21

To perform the maintenance of the meter, it is necessary to remove some parts of the flowmeter. Check below drawings for reference.

Models M21-R, M21-N, M21-1, M21-3, M21-7, M21-30

A special tool is necessary to disassemble the flowmeter float (3). This tool can be supplied on demand by Tecfluid S.A. This tool fits over the top float guide (4).

Once the tool is fitted on the top float guide (4), the nut (1) is unscrewed using a socket spanner number 5.5. In this way the nut, the lockwasher and the bottom float guide (2) can be removed. The float (3) can be extracted from the opposite side.

With the float removed, it can be cleaned and the inside of the flowmeter can also be cleaned.




To remove adhered chemical dirt to the float, the metering tube (6) or the calibrated orifice (5), clean the parts with suitable products or solvents and soft brushes, never use metallic tools.

To reassemble the different components in the flowmeter, proceed as follows:

Introduce the float (3) into the top of the metering tube (6) (the thin end should go first). Do this with care so as not to knock and damage the metering orifice.

Once the float (3) is seated, maintain it in its position using the special tool and turn the instrument upside down. Using a fine rod of 2 to 2.5 mm diameter (for example a fine screwdriver) as a guide, slide the bottom float guide (2) and the washer onto the end of the float. Then mount and tighten the nut (1) using the socket spanner.



Take care to keep the special tool in its correct position during assembly, manually or held in a vice to make assembly easier.


If you are interested in acquiring the special tool from TECFLUID S.A. please indicate for which nominal diameter it is required.

Models M21/HR, M21/HN, M21/HRA, M21/HNA

To dismount the float, the plug (8) should be unscrewed and the PTFE seal (7) removed.

By turning the instrument upside down the float will slide out. Be careful that the float does not fall and gets damaged itself.

With the float removed, it can be cleaned and the inside of the flowmeter can also be cleaned.



17.2 M21 with damping system

For these models it is recommended to send the flowmeter to Tecfluid S.A. facilities, in order to perform its maintenance.

17.3 Potential problems with the metering tube

17.3.1 Jammed float

To remove the float, follow the steps in section 17.1.



To remove adhered chemical dirt to the float, the metering tube or the calibrated orifice, clean the parts with suitable products or solvents and soft brushes, never use metallic tools.

The float may also become clogged by accumulation of metallic particles around it due to the float magnetic field. In this case install a magnetic filter on the inlet of the meter, or just a normal filter depending on the size and nature of the particles.

Follow the steps in section 17.1 to reassemble the flowmeter.

17.3.2 Lack of magnetic field

Disassemble the float as indicated in section point 17.1. Check if the float has suffered chemical attack and if so the permanent magnet has been affected. If this is the case, the float must be replaced and the flowmeter will have to be re-calibrated at Tecfluid S.A. facilities.

17.3.3 Damaged calibrated orifice and/or float

Check that they do not show any impacts or scratches. Also check for any chemical attack. If the float is in bad condition it must be replaced. If the calibrated orifice is damaged, the metering tube and the float must be replaced. In both cases the flowmeter has to be re-calibrated at Tecfluid S.A. facilities.

17.4 Potential problems with the indicator housing

17.4.1 The indicator pointer rubs on the reading scale

To remove the cover (6), remove the four screws M4 at the corners of the indicator housing.


Rubbing normally happens if the meter has been hit or dropped. Simply straighten the pointer (2) by bending it slightly until it is separated between 2-3 mm from the reading scale surface (5).

17.4.2 Deviation of the zero on the scale

When the indicator pointer (2) does not point zero in its rest position, place the flowmeter in its real working position on top of a non-magnetic table. If when the float is moved the pointer moves but does not return to 0, check that the pointer hub (3) is firmly attached to the pointer shaft (1). If it is not, secure the pointer hub (3) onto the conical tip (1) of the shaft by tapping it lightly and carefully.

If the pointer hub is fixed, make the indicator pointer coincide with the 0 on the scale using the frontal adjusting screw (4) on the indicator pointer. Make sure that the shaft (1) is held fast so as not to be bent or damaged.


Check that there is no rubbing between the pointer movement system and the cables connected to a limit switch or transmitter.



17.5 RCA regulator maintenance

For the maintenance process, the regulator must be completely disassembled. To do so, follow disassembly steps 1 to 6:

1. Unscrew the connection (1) that connects the valve body (4) with the flow meter M21.
2. Unscrew the connection (12) that joins the diaphragm body (7) with the fluid outlet "T".
3. Unscrew the 6 M6 screws (8). Remove them together with the washers.
4. Separate the bodies (7) and (4). The spring (11), the diaphragm (2) and the valve seat (5) will be visible.
5. To release the diaphragm (2) unscrew the nut (10).
6. To remove the valve seat (5) and the shaft (3), use an angled pivot wrench to clean the deposition chamber.



To reassemble the assembly, follow assembly steps 7 to 13:

7. Replace the shaft (3) and the valve seat (5) with its respective gasket. Again using the angled pivot wrench.
8. Place the diaphragm (2) so that the holes coincide with the threaded holes of the valve body (4) and fix it again with the nut (10) to the guide disk (6).
9. Place the spring (11) centering it to the support washer (9) and making it rest on the valve seat (6).
10. Position the diaphragm body (7) so that the 6 holes match those of the regulating diaphragm (2).
11. Place and tighten the M6 screws (8), with their respective washers, alternately crosswise, to ensure uniform pressure on the entire sealing surface of the membrane.
12. Thread the connection (1) that joins the valve body (4) to the M21 flow meter.
13. Thread the connection (12) that joins the diaphragm body (7) to the fluid outlet "T".


17.6 RCD regulator maintenance

For the maintenance process, the regulator must be completely disassembled. To do so, follow disassembly steps 1 to 7:

1. Unscrew the connection (4) that joins the valve body (8) with flow meter M21.
2. Unscrew the connection (1) that joins the fluid inlet "T" to the diaphragm body (10).
3. Unscrew the 6 M6 screws (3). Remove them together with the washers.
4. Separate the bodies (8) and (10). The spring (5), the regulating diaphragm (9), the guide disk (2) and the shaft (6) will be visible.
5. Unscrew the guide disk (2) from the support washer (11) housed in the regulating diaphragm (9).
6. To remove the valve seat (7), use an angled pivot wrench to clean the deposition chamber.
7. Clean with compressed air or with a cloth or paper dampened with alcohol.

To reassemble the assembly, follow assembly steps 8 to 15:

8. Screw the guide disk (2) to the support washer (11).
9. Re-thread the valve seat (7) to the valve body (8) with the angled pivot wrench.
10. Insert the spring (5) into the valve seat housing (7).
11. Insert the guide disk (2) through the hole in the valve body (8).
12. Position the regulating diaphragm (9) so that its holes coincide with the threaded holes in the valve body (8).
13. Position the diaphragm body (10) so that the 6 holes coincide with those of the regulating diaphragm (9).
14. Place and tighten the M6 screws (3), with their respective washers, alternately crosswise, to ensure uniform pressure on the entire sealing surface of the membrane.
15. Thread the connection (1) that joins the fluid inlet "T" to the diaphragm body (10).
16. Thread the connection (4) that joins the valve body (8) to the M21 flow meter.



17.7 AMD limit switch maintenance

17.7.1 Electrical verification

Check that the voltage at the terminals + and - is over 7.5 V when the vane is in the slot. Connect a multimeter with the scale in DC mA, in series with the terminal +.

Verify that the current is less than 1 mA when the vane is into the slot and more than 3 mA when the vane is out of the slot.


The verification can be done with the following circuit diagram:

Without the sensor, the operation of the amplifier can be checked by using the following circuit diagram:


With the potentiometer the current through the NAMUR amplifier can be modified. The switching point must be between 1.2 mA and 2.1 mA. That is, with the current below 1.2 mA the output relay must have a state and above 2.1 mA the output relay must have the other state.

17.8 TH6 transmitter maintenance

No special maintenance is required.



Without the sensor, the operation of the amplifier can be checked by using the following circuit diagram:



18 TECHNICAL CHARACTERISTICS

18.1 Series M21

Accuracy:	According to VDI/VDE 3513 sheet 2 (qG=50%): 4%
Scales:	Direct in engineering units or in %
Mounting length:	160 mm (168 mm in M21-H)
Scale range:	10:1
Fluid density:	No restrictions
Working temperature:	-80°C ... +250°C (without limit switches / transmitters) -80°C ... +200°C (with limit switches / transmitters)
Ambient temperature:	-20°C ... +80°C
Working pressure:	PN40 without regulation valve PN16 with regulation valve
Connections:	M21-R / N Vertical inlet and outlet BSP / NPT M21-HR / HN Horizontal inlet and outlet BSP / NPT, without valve M21-HRA / HNA Horizontal inlet and outlet BSP / NPT + valve on the inlet M21-1 / 3 / 7 / 30 Vertical inlet and outlet sanitary
Housing:	IP65

18.2 AMD limit switch

Nominal voltage	8 V
Working voltage	5 ... 25 V
Power supply internal resistance	1 k Ω
Current with the vane into the slot	< 1 mA
Current with the vane out of the slot	$\geq$ 3 mA
Standard:	DIN EN 60947-5-6 (NAMUR)
Ambient temperature	-25°C ... +100°C
Type of protection:	IP67

18.3 TH6 transmitter

18.3.1 Power supply

2-wire

Minimum voltage (TH6): 0.02 Z + 12 (Volt) (Z is the load in the current loop in Ohm)
The minimum value is 12 VDC for Z=0 Ohm

Minimum voltage (TH6H): 0.02 (Z+Rext) + 14 (Volt) (Z is the load in the current loop in Ohm)
The minimum value is 18 VDC for Z=0 Ohm and Rext=200 Ohm

Maximum voltage: 36 VDC (for Ex version see section 20.4)

Consumption: maximum 20 mA

18.3.2 Outputs

Analog output: 4 - 20 mA, factory calibrated

Maximum load in the 4-20 loop: 1.1 k Ω (for a 36 VDC supply voltage)
(for Ex version see section 20.4)

18.3.3 General characteristics

Protection of enclosure: IP65

Cable gland: M12 x 1.5

Ambient temperature: -20°C ... +70°C
(for Ex version see section 20.4)

Accuracy (analog output respect the magnetic field): < 0.6 %

19 SAFETY INSTRUCTIONS

The series M21 flowmeters are in conformity with all essential requirements of all EC directives applicable to them:

2014/68/EU Pressure equipment directive (PED)

Limit switches and transmitters:

2014/30/EU Electromagnetic compatibility directive (EMC)

2012/19/EU Waste electric and electronic equipment (WEEE).

Equipment for hazardous areas:

2014/34/EU Equipment and protective systems intended for use in potentially explosive atmospheres (ATEX).

In the last sections of this manual the EC type certificate and the declarations of conformity according to the ATEX directive are attached.

Other declarations of conformity EC can be downloaded from the section "Download" of the Tecfluid S.A. website.



19.1 Pressure equipment directive

Devices of series M21, due to their size, are rated as Category I and are not within the scope of the directive and therefore they have not the CE mark according to pressure directive. These devices are subject to applicable sound engineering practice (SEP).



This equipment is considered as being a pressure accessory and **NOT** a safety accessory as defined in the 2014/68/EU directive, Article 2, paragraph 4.

19.2 Certificate of conformity TR CU (EAC marking)

Tecfluid S.A. have subjected the series M21 of flowmeters to a certification procedure according to the technical regulations of the Customs Union of the Eurasian Economic Union (EEU).



This Certificate is an official document confirming the quality of production with the standards on the territory of the Customs Union, particularly regarding safety requirements and electromagnetic compatibility.

20 ADDITIONAL INSTRUCTIONS FOR THE ATEX VERSION

This chapter only applies to equipment intended for use in explosive atmospheres.

These equipment conform with the directive 2014/34/EU (Equipment and protective systems intended for use in potentially explosive atmospheres) as indicated in the EC-type examination certificate and in its marking.

Given that this instrument is group II, it is intended for use in places likely to become endangered by explosive atmospheres, but not in mines.

The category is 1GD, that is, it is intended for use in areas in which explosive atmospheres caused by mixtures of air and gases, vapours, mists or dust are present continuously, for long periods or frequently.

20.1 Non-metallic parts



WARNING: POTENTIAL RISK OF ELECTROSTATIC CHARGE

The front of the housing consists of a transparent plastic window in order to let the user see the position of the pointer on the scale.

Since the danger of ignition by electrostatic discharge when rubbing this window can not be avoided, **the instrument must always be cleaned with a damp cloth.**



WARNING: RISK OF IMPACT

Because the housing base is made of aluminium, **the equipment must be installed and operated always in locations at low risk of impact.**




WARNING: WIRING

The wiring of the variants containing transmitter and inductive sensor must be kept separated.

20.2 Connecting conductive parts to earth

When the instrument is not grounded securely through the connection process, it should be grounded through the housing screw, as shown in the figure.



Earth connection

20.3 AMD limit switch

When the equipment includes an AMD limit switch, it is certified as intrinsic safety with the following parameters:

Specific parameters	Ui : 16 V
	Ii : 25 mA
	Pi : 64 mW
	Ci : 30 nF
	Li : 100 uH

20.4 TH6 transmitters

Transmitters TH6 are certified to be installed in potentially explosive atmospheres. They are intrinsic safety devices.

The electrical connection and the information with respect to the HART protocol is the same as in the TH6 transmitter (see sections 11 to 16).

The technical characteristics that differ from TH6 transmitters are the following:

- Maximum voltage: 30 VDC
- Maximum load in the 4-20 loop: 900 Ω (at 30 VDC supply voltage)
- Ambient temperature: -20°C ... +40°C

The rest of characteristics are the same as TH6 transmitter (see section18.3).

The specific intrinsic safety parameters are the following:



Specific parameters	Ui : 30 V
	Pi : 1 W
	Ci : 56 nF
	Li : 0 H

20.5 Marking

An example of marking is shown as follows.

The marking of the equipment shows the following characteristics:

- Manufacturer
- Model
- Serial number
- CE marking
- ATEX marking
- Certification number
- Address of the manufacturer





21 FLOW RANGES

Thread size BSP / NPT	Model N.	Flow scales		
		Float EN 1.4404 (AISI 316L) (7,95 g/cm³)		
		I/h water	NI/h air 1.013 bar abs 20°C	ΔP (mbar)
¼"	M21004	0.4-4	12-120	28
	M21006	0.6-6	18-180	28
¼"	M21010	1-10	30-300	30
	M21016	1.6-16	50-490	30
	M21100	2.5-25	80-770	30
¼"	M21040	4-40	120-1200	32
	M21060	6-60	160-1800	32
	M21100	10-100	300-3000	32
½"	M21160	16-160	500-4900	34
	M21250	25-250	800-7700	34
½"	M21400	40-400	1200-12000	40
	M21630	60-630	1800-18000	40
¾"	M21M01	100-1000	3000-30000	40

22 DIMENSIONS


Threads BSP / NPT



R	A
1/4"	65
1/2"	69
3/4"	72

(dimensions in mm)


NPT Thread connection with Damping System



R	L (NPT)	A
1/4"	201	66
1/2"	212	69
3/4"	222	72

(dimensions in mm)


Sanitary connections DIN 11851 & SMS ISO 1145)



DN	A
10	66
15	68
20 / 25	69

(dimensions in mm)


Sanitary connection CLAMP ISO 2852 (EN 1.4404)



DN		A	C ₇
CLAMP	TRI-CLAMP®		
12	¾"	65	34
21,3	1"	69	34
22,6	1"	72	50,5

(dimensions in mm)

Indicator box EN 1.4404 (AISI 316L)



Rp	A
1/4"	67
1/2"	71
3/4"	74

(dimensions in mm)



LABORATORIO OFICIAL J. M. MADARIAGA

**EU-TYPE EXAMINATION CERTIFICATE**

Equipment or protective systems Intended for use in Potentially Explosive Atmospheres – Directive 2014/34/EU

EU-Type Examination Certificate Number **LOM 13ATEX2001X** Issue: **1**Product Flow meters
Types M21 y AD**

Manufacturer Tecfluid S.A.

Address Narcís Monturiol, 33
08090 Sant Just Desvern (BARCELONA)
SPAIN

This product and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.

El Laboratorio Oficial J.M. Madariaga (LOM), Notified Body No. 0163, in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and of the Council, dated 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential Report **LOM 22.341S**

Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

- Standards **EN IEC 60079-0:2018** **EN 60079-11:2012**

Where additional criteria beyond those given here have been used, they are listed at item 18 in the Schedule.

10 If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions of Use specified in the schedule to this certificate.

11 This EU-Type Examination Certificate relates only to the design and construction of the specified product in accordance to the Directive 2014/34/EU. Further requirements of the Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate.

12 The marking of the product shall include the following:

II 1G Ex in IIC T6...T4 Gb
II 1D Ex in IIIC T* °C Da

Getafe.

Electronically signed by:

GARCIA TORRENT
FRANCISCO JAVIER -
05356542A
2022.12.29 17:32:23
+01'00'

Certification Committee

RCPCR 25/7/7

(This document may only be reproduced in its entirety and without any change)

Page 1/3

UNIVERSIDAD POLITÉCNICA DE MADRID
(Real Decreto 334/1992 de 3 de Abril - BOE 1992-04-29)

Eric Kandel, 1 - 28906 GETAFE (MADRID) • (34) 910 679 825 • lom@lom.upm.es



LABORATORIO OFICIAL J. M. MADARIAGA

13 SCHEDULE

14 EU-Type Examination Certificate Number: **LOM 13ATEX2001X**

Issue: 1

15 Description of product

M21 and AD * flow meters are based on a section of pipe through pass a fluid, in some cases by displacing a float and other displacing a disk. Attached to the pipe is placed an enclosure containing the reading flow system. This enclosure can be made of aluminium, stainless steel or polypropylene.


Types and variants	M21	Flow meter with conical float with reading system enclosure
	AD	Impact disk flow meter without reading system enclosure
	ADI	Impact disk flow meter without reading system enclosure

The equipment with two wire transmission include a circuit called HALLTEC VI having two variants, TH6 with 4-20 mA output and TH6H with HART support.

Equipment with limit switch detectors include one or two detectors:

M1-AMD1	One NAMUR inductive detector
M1-AMD2	Two NAMUR inductive detector
1A	One reed micro-switch
2A	Two reed micro-switch

Type codification:



Specific parameters of the type of protection

Variants with transmitter TH6 / TH6H	Variants with transmitter TH6 / TH6H Encapsulated	Variants that only include inductive detectors	Variants that only include reed micro switches	
Ex ia IIC T4 Ga	Ex ia IIC T6 Ga Ex ia IIIC T200 85 °C	Ex ia IIC T6 Ga Ex ia IIIC T200 85 °C Da	Ex ia IIC T6 Ga	Ex ia IIIC T135 °C Da
<i>Ui</i> : 30 V <i>Ci</i> : 56 nF <i>Li</i> : 0 <i>Pi</i> : 1 W	<i>Ui</i> : 30 V <i>Ci</i> : 56 nF <i>Li</i> : 0 <i>Pi</i> : 1 W	<i>Ui</i> : 16 V <i>Ii</i> : 25mA <i>Pi</i> : 64 mW <i>Ci</i> : 30nF <i>Li</i> : 100 µH	<i>Ci</i> : 0 <i>Li</i> : 0	<i>Pi</i> : 750 mW <i>Ii</i> : 250 mA <i>Ci</i> : 0 <i>Li</i> : 0

When combined variants with transmitter and inductive sensors, the connection of the respective circuits should be kept separate by independent cables.

Changes in this issue

- Update to the standard EN IEC 60079-0:2018
- The standard EN 60079-26 is no longer in scope
- Type of protection parameters are updated

16 Report LOM 22.341S

17 Specific conditions of use

- The variants with aluminium enclosures shall only be installed in locations with low risk of mechanical impact.
- There is a risk of electrostatic charge due to the part of the enclosure in polypropylene and to the plastic window part. The manufacturer's safety manual shall be followed.
- The wiring of the variants that incorporate a transmitter and inductive detector must be kept separately



LABORATORIO OFICIAL J. M. MADARIAGA

13 ANEXO

14 EU-Type Examination Certificate Number: **LOM 13ATEX2001X**

Issue: 1

18 Essential health and safety requirements

Met by compliance with the requirements mentioned in item 9.

According to Article 41 of Directive 2014/34/EU, EC-type examination certificates which have been issued according to Directive 94/9/EC prior to the date of coming into force of Directive 2014/34/EU (April 20, 2016) may be considered as if they were issued already in compliance with Directive 2014/34/EU. By permission of the European Commission, supplements to such EC-type examination certificates and new issues of such certificates may continue to hold the original certificate number issued before April 20, 2016.

19 Drawings and Documents

Number	Sheets	Issue	Date	Description
R-ET-AV2ATEX	11	2	2022-11-04	(*) Technical dossier
P239520071	1	0	2011-09-10	Haltree VI schematics
2689101006	1	1	2022-12-22	(*) Marking label
P239520071_02	2	0	2012-04-04	Component list
P693120046_03	1	0	2012-08-29	PCB drawing
P116810010_02	2	0	2012-02-17	M21 ADI set and part list
P116810012_02	2	0	2012-02-17	M21 ADI + 1 AMD set and part list
P116810014_02	2	0	2012-02-17	M21 ADI + 2 AMD set and part list
P116810016_02	2	0	2012-02-17	M21 ADI + TH6 set and part list
R-MI-AD15	32	4	2022-12	(*) Series AD user manual
R-MI-M21	44	5	2022-12	(*) Series M21 user manual

20 History of variations

Issue	Date	Number of report	Description
0	2013-01-22	LOM 12.475 VP	First certificate

(This document may only be reproduced in its entirety and without any change)

Page 3/3



UE Declaration of Conformity

Manufacturer: TECFLUID S.A.
Narcís Monturiol, 33
E 08960 Sant Just Desvern

Equipment: Series M21 and AD of flow meters

Models: M21, AD, ADI

Switches: AMD1, AMD2, 1A, 2A

Transmitters: TH6, TH6H

Certification: LOM 13ATEX2001X

Group and category:  II 1G Ex ia IIC T4 ... T6 Ga
II 1D Ex ia IIIC T₂₀₀ 85°C Da

Standards to which conformity is declared:

Directive ATEX 2014/34/EU

EN60079-0:2018 Equipment. General requirements

EN6009-11:2012 Equipment protection by intrinsic safety "I"

Changes in the current standards regarding the standards mentioned in this declaration of conformity do not affect the EC-type examination certificate LOM 13ATEX2001 X corresponding to this equipment

For production, Tecfluid S.A. complies with the Module D (annex IV) of the directive 2014/34/EU, having the notification for production quality assurance n. LOM 02ATEX9033, of the notified body with identification number 0163 (Laboratorio Oficial J.M. Madariaga)

I, the undersigned, declare that the equipment stated above is in conformity with the essential requirements of the Directives of the European Parliament and the Council on the approximation of the laws of Member States concerning equipment and protective systems intended for use in potentially explosive atmospheres.

In Sant Just Desvern
Date: October 7, 2022

Alberto Barea (Responsible for Ex Products)

WARRANTY

Tecfluid S.A. guarantees all its products for a period of 24 months from the date of sale, against any defect in materials, manufacture or operation. Excluded from this warranty are failures that can be attributed to improper use or application other than that specified in the order, handling by personnel not authorized by Tecfluid S.A., mishandling and mistreatment.

This warranty is limited to the replacement or repair of parts in which defects are observed that have not been caused by misuse, excluding liability for any other damage, or for the effects produced by the wear and tear of normal use of the equipment.

For all shipments of material for repair, a process is established that should be consulted on the web page www.tecfluid.com section of After Sales.

The products sent to our facilities must be properly packed, clean and completely free of liquids, grease or harmful substances.

The equipment to be repaired must be accompanied by the form to be filled in via web in the same After Sales section.

The warranty for repaired or replaced components applies for 6 months from the date of repair or replacement. However, the warranty period, as a minimum, will remain in force as long as the initial warranty period of the object of supply has not expired.

TRANSPORTATION

Shipments of Buyer's equipment to Seller's facilities for credit, repair or replacement shall always be made carriage prepaid unless otherwise agreed.

Seller accepts no responsibility for damage to equipment in transit.



Tecfluid S.A.

Narcís Monturiol 33

08960 Sant Just Desvern

Barcelona

Tel: +34 93 372 45 11

Fax: +34 93 473 08 54

tecfluid@tecfluid.com

www.tecfluid.com

Quality Management System ISO 9001 certified by



Pressure Equipment Directive certified by



Lloyd's Register

ATEX European Directive certified by



HART is a trademark of FieldComm Group TM

The technical data described in this manual is subject to modification without notification if the technical innovations in the manufacturing processes so require.